YL LIGHT

# 5 x 120W RGBL Tornado Moving Bar - Series 2

## DMX AND CONTROL REFERENCE - EXCERPT

This edition contains the model-specific operation and DMX reference page from the associated product guide. The reference page is reproduced in its existing layout, with all stated mode and firmware limitations retained.

This is a control-reference excerpt, not a complete installation or operating manual. It does not specify an operating-temperature range, power connection rating or approved rigging design. Confirm those items for the supplied fixture before installation.

Match the console patch to the actual fixture mode. Modes shown as manual-listed or unverified remain subject to the confirmation notes printed on the following page.

Guangzhou Yeliang Optoelectronic Technology Co., Ltd.
https://ylaudiolight.com/ | info@ylaudiolight.com
WhatsApp: +86 157 7061 9135

# 2. Operation, Menu and DMX Modes

Use MENU to enter functions, UP/DOWN to edit and ENTER to save. Current manuals and supplied fixture files cover 31CH, 41CH, 51CH, 71CH and 79CH.

| | |
|---|---|
| **31CH** | Grouped movement, main light, auxiliary effects and reset |
| **41CH / 51CH** | Independent or grouped motion with direct color access |
| **71CH / 79CH** | Extended per-head and auxiliary-pixel control |

## COMMISSIONING

Secure the fixture and safety cable; verify the nameplate, earth and cabling; connect power and DMX; select a mode and start address; then test five heads, focus, RGBL main light, RGB auxiliary light, dimming, strobe and reset.

**Fixture authority: use the current-product fixture file matching the selected mode; never copy channel data from another product.**